

# 2022 to Current Toyota Tundra Without Deck Rail Mounting Solution

One 14mm wrench and one 4.5mm Hex Key wrench needed to install.

1. Locate the mounting hole that aligns with the center of the side rail slot.



2. Insert the M6 bolt into the clamp base. Use 2 each 1/2" plastic spacers between the clamp base and the vehicle. Tighten the clamp base to the vehicle with a 4.5mm Hex Key. DO NOT OVER TIGHTEN.



3. Install the upper clamp into the side rail slot. Insert the 3/8" flange head bolt through the bottom of the base clamp and thread into the upper clamp.



4. With the 14mm wrench, tighten the flange head bolt to secure the side rail to the vehicle. DO NOT OVER TIGHTEN.

