

SOFTOPPER[®]

Notes for the installation and operation of the Chevrolet Colorado ZR2 Bison Edition
and GMC Canyon AT4X AEV Edition



Note:

Placement of the front left side clamp should be attached in front of the bed mounted spare tire.
(About 15 1/2 inches)



1. Due to the location of the AEV vertical tire mounting system, the Softopper must retract to the rear of the bed on top of the tailgate.
2. While leaving the 2 safety straps out, place canopy in protective boot cover, and secure the boot cover straps.

Note:

****DO NOT OPERATE VEHICLE WITH SOFTOPPER IN RETRACTED POSITION WITHOUT INSTALLING THE BOOT COVER.** A parachuting effect may occur while driving without boot cover secured over canopy in its retracted position.

3. Once the canopy is in the protective boot cover, hook the 2 safety straps back onto the rear bar retainers and tighten.

